OPERATION AND INSTALLATION MANUAL



Corporate Headquarters 3860 Calle Fortunada San Diego, CA 92123-1825 Phone: (858) 278-2900 FAX: (858) 278-6700 Web-Site: http://www.hardyinst.com

Hardy Instruments Document Number: 0596-0241-01 REV A-1 Copyright November 1999 Hardy Instruments, Inc. All Rights Reserved. Printed in the U.S.A. (941028)

Table of Contents

TABLE OF CONTENTS
TABLE OF ILLUSTRATIONS
CHAPTER 1 - OVERVIEW
A Brief Description of Chapter 1
CHAPTER 2 - REQUIREMENTS
General Introduction to Chapter 2
CHAPTER 3 - INSTALLATION
Installing the Hardy Instruments Configuration Software
CHAPTER 4 - SETUP
A Brief Description of Chapter 4

CHAPTER 5 - OPERATING PROCEDURES	1
A Brief Description of Chapter 5	1 1 2 2 2
Calibration Procedures	2 2 3 4 5 8 8 8 9 10
CHAPTER 6 - TROUBLESHOOTING	1
A Brief Description of Chapter 6	1 1

Table of Illustrations

СНА	PTE	R 3 - INSTALLATION
FIG.	3-1	C2 LOAD CELL CONNECTION/HI 215IT JUNCTION BOX
FIG.	3-2	NON C2 LOAD CELL CONNECTION/HI 215IT JUNCTION BOX
СНА	PTE	R 4 - SETUP
FIG.	4-1	INTRO PAGE
FIG.	4-2	COMM SETUP
FIG.	4-3	REMOTE SELECTED/ENTER FILE#, STARTING WORD -4-5
FIG.	4-4	SAMPLE OF REQUIRED LADDER LOGIC
		FOR INTEGER TYPE FILES SLC 5/02
FIG.	4-5	CHECKING "USE INTEGER FILE "/SLC 5/02 4-7
FIG.	4-6	HI 1746WS REMOTE RACK LADDER LOGIC 4-11
СНА	PTE	R 5 - OPERATING PROCEDURES
FIG.	5-1	LIVE WEIGHT PAGE
FIG.	5-2	C2 CALIBRATION
FIG.	5-3	HARD CALIBRATION
FIG.	5-4	SOFT CALIBRATION
FIG.	5-5	PARAMETERS SETTINGS
FIG.	5-6	SETPOINT SCREEN
FIG.	5-7	C2 SERIAL NUMBER SCREEN
FIG.	5-8	REMOTE DISPLAY
СНА	PTE	R 6 - TROUBLESHOOTING
FIG.	6-1	INTEGRATED TECHNICIAN TEST

CHAPTER 1 - OVERVIEW

A Brief Description of Chapter 1

This manual provides the user and service personnel with a description of the specifications, installation, setup, operation, communication procedures for the Hardy Instrument's HI 100WS Configuration Software to configure the HI 1746-WS Weigh Scale Module, designed for use in Allen-Bradley's SLC $5/02^{\odot}$, 5/03, 5/04, 5/05 programmable controllers. Chapter 1 provides a general introduction to the HI WS100 Configuration Software. The HI 100WS Software is C2[®] and INTEGRATED TECHNICIAN $(IT)^{\text{®}}$ enabled. The HI 100WS Software is designed to run on the Windows[®] 95/98/NT/2000 platforms in conjunction with Allen-Bradley's RS Linx[©] or RS Linx Lite[©] Industrial Programming Software for Windows[®] 95/98/NT/2000. To get the maximum service from this product, users should operate this software in accordance with recommended practices either implied or expressed in this manual. Before using the HI WS100 Software, all users and maintenance personnel should read and understand all cautions, warnings, and safety procedures, referenced or explicitly stated in this manual. Hardy Instruments appreciates your business. Should you not understand any information in this manual or experience any problems with the product, please contact our Customer Support Department at:

Phone: (858) 278-2900 FAX: (858) 278-6700 e-mail: support@hardyinst.com Web Address: hardyinst.com

C2[®], INTEGRATED TECHNICIAN[®] are registered trademarks of Hardy Instruments Inc. Windows[®] is a registered trademark of the Microsoft Corporation. RSLinx[®] and RSLinx Lite[®] SLC 500[®] are registered trademarks of the Rockwell Corporation.

Hardy Instruments bases all procedures on the assumption that the user has an adequate understand-

NOTE:

NOTE:

ing of all Allen-Bradley SLC 500 products. In addition the user should understand process control and be able to interpret ladder logic instructions necessary to generate the electronic signals that control your application(s).

About Hardy Manuals

Every Hardy Installation and Operation manual is organized into easily referenced chapters, that are almost always the same:

- **Chapter 1** Provides an introduction to the instrument and an **Overview** of the equipment and its capabilities.
- Chapter 2 Provides a complete list of Specifications.
- **Chapter 3** Contains information needed to install the HI 1746-WS (both standard and optional equipment) and the HI 215IT series Junction Box.
- Chapter 4 Provides complete hardware Configuration instructions for setting dip switches and jumpers.
- **Chapter 5** Pertains to the firmware/software **Setup** and preparation procedures to calibrate and operate the instrument.
- Chapter 6 Provides all Calibration instructions.
- Chapter 7 Pertains to the Operating Procedures of the HI 1746-WS.
- Chapter 8 Pertains to the Troubleshooting procedures for repair of the instrument.

Hardy Instruments hopes that this manual meets your needs for information and operation. All corrections or suggestions for improvements of this manual are welcome and can be sent to the Technical Publications Department or Customer Support Department at Hardy Instruments Inc.

Description The HI WS100 Configuration Software is a program that enables the user to configure a remote HI 1746-WS Weigh Scale Module. The HI 1746-WS Weigh Scale Module is a self contained microprocessor based I/O module with control inputs and outputs, that is designed to be easily plugged into the back plane of an Allen-Bradley SLC 5/02, 5/03, 5/04 or 5/05 programmable controller and/or Remote Rack. The HI 100WS is IT enabled which means you can perform the INTEGRATED TECHNICIAN (**IT**) Tests.

C2[®] Calibration C2 Second Generation Calibration enables a scale system to be calibrated electronically without using certified test weights which equal the systems load capacity. A C2 weighing system consists of up to eight (8) C2 load sensors, a junction box, interconnect cable and an instrument with C2 capabilities such as the HI 1746-WS Weight Scale Module. All Hardy Instruments C2 certified load sensors contain digital information detailing its unique performance characteristics. If the system is fitted with C2 type load cells the HI WS100 software displays the serial numbers programmed into each load cell. From the serial numbers the operator can look up the parameters of each loadcell by going to the Hardy Instruments Internet Site. http://www.hardyinst.com

> **INTEGRATED TECHNICIAN[®]** is a system diagnostics utility which continuously monitors the weighing system (with up to 4 load sensors) for possible malfunctions. For full functionality the HI 215IT junction box (J Box) should be used. Full *IT* functionality allows the operator to rapidly troubleshoot a weighing system from the HI 100WS Configuration Software, Parameters Edit Display. The test are:

- Loadcell Impedance The user can see the impedance determined at calibration (Base R), the impedance found during the test (Read R), and the test result (Good or Bad). also shown are the volts at the loadcells at calibration (Sense V), and the current going to the load cells at the time of the reading.
- **RTZ** (Return to Zero) This test gives a pass/fail on whether there is a zero load. If you have a "J Box", individual load cells can be tested. If you do not have a :"J Box" the test is done on the combined loadcells.

- **DVM** (Digital Volt Meter) If you have a "J Box", the voltage outputs from the individual loadcells can be read. If you do not have a "J Box" the voltage is a combined voltage output from all loadcells in the system.
- **System Test** If you have a "J Box" you can read the weight being read on individual load cells and the internal reference.

Requires the HI 215IT Junction Box. This test is used to diagnose drifting or unstable weight reading problems. The Weighing System Test does the following:

- 1. Disconnects the controller and engages an internal reference signal to see if the problem is within the instrument.
- 1. Disconnects the load sensors and engages an internal (in the junction box) reference signal to see if the cable between the instrument and the Junction Box is causing the problem.
- 2. Reads the weight of each load sensor to see if the load sensor might be causing the problem.

The ability to read the weight seen by each individual load sensor allows use of this test to make cornering, leveling and load sharing adjustments to the weighing system.

Weighing System Tests - Optional

CHAPTER 2 - REQUIREMENTS

General Introduction to Chapter 2	All the information in Chapter 2 pertains to the hard- ware and software requirements for HI WS100 Con- figuration Software. These requirements are the minimum requirements for loading and operating HI WS100 Configuration Software. Check to see if the personal computer on which you want to install HI WS100 Configuration Software, meets these require- ments. It is very important that the user be familiar with this section before installing or operating this software.		
Operating System Requirements	 HI WS100 Configuration Software runs on the following operating systems: Windows NT 4.0/2000 Windows 95/98 		
Minimum Hardware Requirements	 HI WS100 Configuration Software requires the following hardware: CPU - Pentium[®] 133 MHz or better 3 MB free space on your hard drive RAM - 16 MB Monitors - SVGA, configured for 640 x 480 resolution or better Floppy Drive - 3.5", 1.44 MB drive or better 		
NOTE:	The HI WS100 must run in conjunction with Allen Bradley's RS LINX or RS LINX LITE therefore the HI WS100 hardware requirements are in addition to hardware requirements for RS LINX or RS LINX LITE.		
Software Requirements	Allen Bradley's RS LINX [®] or RS LINX [®] LITE software.		
RSLogix OR EQUAL (FOR REMOTE MODE OPERATION ONLY)	Allen Bradley's RSLOGIX [®] software or equivalent.		
NOTE:	RSLOGIX [®] is a registered trademark of the Rockwell Corporation.		

CHAPTER 3 - INSTALLATION

Installing the Hardy Instruments Configuration Software	Contact your local Hardy Representative or Hardy Instruments Sales Department for information about how to purchase the Hardy WS 100 Configuration Software for Windows.			
	Step 1.	The SETUP program copies the required files to your hard disk.		
	Step 2.	Run Windows NT/95/98/2000 and insert the Configuration Installation System Disk into the 3.5" floppy drive.		
	Step 3.	Click on START.		
	Step 4.	Click on Run.		
	Step 5.	In the Run field type the command: a:setup. If your floppy drive is drive b enter: b:setup.		
	Step 6.	Press the Enter key.		
	Step 7.	You can also use the Add/Remove Func- tion in the Control Panel dialogue box.		
	1	Click on Start		
	1	Move the cursor to Settings.		
	1	Select Control Panel.		
	1	Double click on the Add/Remove Programs icon.		
	1	Click on the Install button.		
	Step 8.	The SETUP program will lead you through the installation process.		
Installation of RSLOGIX	Please r Operatio	efer to your Allen Bradley Installation and on manual for instructions.		
Installation of RSLINX or RSLINX Lite	Please refer to your Allen Bradley Installation and Operation manual for instructions.			

Wiring Diagram for the HI 215IT Junction Box

C2 Loadcell	When connecting the HI 215IT Junction box using C2
Cable	loadcell/point cable (6020-0001) use the following
Connection (J1)	color code:

<u>Model</u>	EXC +	SEN +	SIG +	SIG -	SEN -	EXC -	C2 +	C2 -
J-BOX	RED	BLUE	GRN	WHT	BRWN	BLK	GREY	VIO

Table 1: C2 CABLE COLOR CODE/HI 215IT J-BOX



FIG. 3-1 C2 LOAD CELL CONNECTION/HI 215IT JUNCTION BOX

- 1 Recommended load cell cable, Hardy Instruments (Prt. #6020-0001)
- 2 Attach the load shield to the terminal block mounted next to the J1 connector on the HI 200DNWM Module.

- 3 Do not run load cell cable in parallel with or in the same conduit with power wiring, relay cables or any other high energy cables.
- 4 Remove the factory installed jumpers for C2 wire load cell connection.
- 5 IT summing Card (Prt. #0535-0465)
- 1 Attach the load cell cable to the terminal block mounted next to the J1 connector on the HI 200DNWM Module.
- 2 Factory installed jumpers to remain in place for 4 wire load cell connection.
- 3 Do not run load cell cable in parallel with or in the same conduit with power wiring, relay cables or any other high energy cables.
- 4 Eight (8) conductor load cell cable required when:
 - Cable runs are greater than 50 feet.

With Soft Calibration



FIG. 3-2 NON C2 LOAD CELL CONNECTION/HI 215IT JUNCTION BOX

Non-C2 Loadcell Cable Connection (J1)

CHAPTER 4 - SETUP

A Brief Description of Chapter 4	All information contained in Chapter 4 pertains to firmware and software settings to prepare the HI 1746WS Weight Module controller for calibration and operation. Alternatives to these procedures explicit or implied, contained in this section are not recommended. It is very important that the user and service personnel be familiar with the procedures con- tained in this chapter, before going through the setup procedures. The Setup procedures require either Allen-Bradley DOS PLC 500 AI Series Ladder Logic Editor*, or Allen-Bradley RSLogix 500* and Allen- Bradley RSLinx [™] or RSLinx [™] Lite.			
Presetup Procedures	Step 1.	Make sure that the HI 1746-WS is		
	Step 2.	Make sure that the HI 1746-WS has been setup correctly and that all data necessary to run the HI 1746-WS module has been entered into RSLogix 500 configuration software.		
	Step 3.	Check the module ID code to verify that the jumper has been set for the proper mode of operation (Local ID Code = 13635, Remote ID Code = 3235). If you have put the HI 1746-WS module in a local rack and get the 3235 ID number the jumper is set incorrectly.		
	Step 4.	If you have set the jumper for the HI 1746- WS module for local mode of operation and placed the module in a remote rack the 1747 ASB will display an invalid module error.		
	Step 5.	If these errors occur, remove the HI 1746- WS and reset the jumper to the proper mode of operation. (See the HI 1746-WS Weigh Module Installation and Operation Manual (Prt. #0596-0234-01), Chapter 3, Page 3-2 for instructions)		
	Step 6. Step 7.	Reinstall the module. Repeat Steps 3 & 4.		

NOTE:	If you are using RSLogix 500, the HI 1746-WS (in local mode) is configured as an "Other" card with an I/O module ID code of 13635, M0 and M1 lengths are 128.
NOTE:	If you are using RSLogix 500, the HI 1746-WS (in remote mode) is configured as an "Other" card with an I/O module ID code of 3235, with two input words and two output words. In remote mode the HI 1746- WS has no M files. Instead, it has files inside that cor- respond to the 32 word I and O files of the local mode HI 1746-WS, and to its M files. These files are called "logical" files, meaning that they perform the func- tion of the I,O, and M files in the local mode but are not directly accessible through the SLC backplane.
	Step 8. Double click on the HI WS100 Icon on your Windows Desktop. The HI WS100 will automatically launch RSLinx.
NOTE:	If you are starting HI WS100 for the first time you will get a "Communication Failure" message. Don't worry about this message at this time. The Comm Setup has not been configured yet. Once the HI WS100 has been configured correctly the "Communi- cation Failure" message goes away.
	Step 9. The Intro Sheet displays with the setup instructions in a text field. (See Fig. 4-1) Scroll through the Text field and read the instructions for setting up the HI 100WS Configuration Software before starting the setup procedures.



FIG. 4-1 INTRO PAGE

Setup Procedures

Comm Setup for	Step 1.	Click on the Comm Setup Tab. The Comm
SLC Models		Setup Page appears. (See Fig 4-2)
(Except SLC 5/02)		

😨 Han	dy HI V	/5100		_ 8 ×
Intro	Live	Weight Calibrate Parameters Setpoint Integrated Technician	C2 Comm Setup	Remote
	Slot	Enter Module Slot #		
	Station	1 Enter Station H		
	Driver	AB_DF1-1 Select Driver		
	I Use I Ref	integer file (required by 5/02, meeds ladder logic support) ote7 Fileft 7 stating word 0		
	□ Use	dtsa.txt file?		
[Şav	Settings Saved		

FIG. 4-2 COMM SETUP

- Step 2. Enter the SLC slot number of the installed HI 1746-WS Weigh Module in the Slot textfield.
- Step 3. Enter the Station number of your SLC in the Station textfield. This number must be an Octal number for the Station number.
- Step 4. Select a driver (supplied by RSLinx) by clicking on the down arrow on the "Driver" pull down menu. Click on the driver you want to use to communicate with the HI 1746-WS.

CAUTION:DO NOT CLICK IN THE CHECK BOX NEXT TO
THE "USE DTSA.TXT FILE".

Step 5. If the HI 1746-WS module is installed in a remote rack, click in the check box next to the word "Remote?". (See Fig. 4-3)

28 Hardy HI WS100	- 6	7 ×
Intro Live Weight Calibrate Parameters Setpoint Integrated Technician	C2 Comm Setup Remote	
Slot 1 Enter Module Slot II		
Station 1 Enter Station #		
Driver AB_DF1-1 Select Driver		
Use integer file (sequired by 5/02, meeds ladder logic support) Fett Filett stating word Use dtsa.txt file?		
Settings Saved		

FIG. 4-3 REMOTE SELECTED/ENTER FILE#, STARTING WORD

	Step 6.	Enter the integer number used in the Lad- der Logic for remote operation of the HI 1746-WS Weigh Module in the textfield next to "File#". In our example we entered the number 7.
	Step 7.	Enter the starting number us in the Ladder Logic for remote operation of the HI 1746- WS Weigh Module in the textfield next to "starting word".
	Step 8.	Click on the Save button to save the set- tings.
Comm Setup for the SLC 5/02	Normally the "M Fil munication of M Files and write "	the HI WS100 talks to the HI 1746-WS via es". The SLC 5/02 does not support com- n commands for direct reading and writing . The SLC 5/02 supports commands to read "integer" type files.
	Step 1.	Write the ladder logic provided (See Fig. 4-4) to copy the integer file to the HI 12746-WAS's M files. The ladder logic

enables the HI 1746-WS to read the information in the integer file.



FIG. 4-4 SAMPLE OF REQUIRED LADDER LOGIC FOR INTEGER TYPE FILES SLC 5/02

NOTE:

Our example has the HI 1746-WS weigh module located in slot #3 of the SLC and the integer file #9 (N9) is chosen with the starting word = 0.

Step 2. Click in the check box next to the "Use integer file (required by 5/02, needs ladder logic support)". (See Fig. 4-5) The program will write to the specified integer file number (7,8,9, etc. for N7, N8, N9,...) starting at the specified offset (starting word) within that file. The program

requires a total of 43 integer words: 21 for the M0 file, 21 for the M1 file, and 1 as a flag.

🔁 Hardy HI WS100	
Intro Live Weight Calibrate Parameters Setpoint Integrated Technician I	2 Comm Setup Remote
Slot 1 Enter Module Slot #	
Station 1 Enter Station #	
Driver AB_DF1-1 Select Driver	
Use integer file (required by 5/02, needs ladder logic support) Filemate? Filett Starting word Use dtsa bit file?	
Save	د. ۲ ۱۰ ۱۰

FIG. 4-5 CHECKING "USE INTEGER FILE. . . "/SLC 5/02

Comm Setup for the HI 1746WS Remote Rack	The ladder logic example below must be running so that the WS100 Configuration Software will work with the 1746 module installed in a Remote Rack. Th addresses shown in the ladder logic example are arb trary locations. If the file is added to an existing pro gram, these address locations can be changed for the system to insure there are no conflicts. The color co ing of the locations is as follows:			
Legend	Green:	Slot # for scanner module in local rack and portion of the M file to be used.		
	Yellow:	Integer files used for data defining the M file, (read/write, length, address). Also status/error bits per- taining to the transfers of data.		

- Pink: Integer file specified in the WS 100 program COMM SETUP screen that it will use to read/write data. The WS 100 Configuration Program also specifies the starting word in this file. The WS 100 will 17 words starting at the specified word of the file. The first word is used as a trigger to start the write process. Words 2-9 are the write data, and words 10-17 are the read data.
- No Color: Status bits used for program control.







FIG. 4-6 HI 1746WS REMOTE RACK LADDER LOGIC

In addition the Rate of Change (ROC) and the ROC Units are displayed. Relay 1 and

Relay 2 status are displayed.

CHAPTER 5 - OPERATING PROCEDURES

A Brief Description of Chapter 5	All information contained in Chapter 5 pertains to operation of the HI WS100 Configuration Softw The Operating Procedures include, Reading Live Weight, Calibration, Creating or modifying Set- point(s) Parameters, reading C2 load cell serial to bers and quickly monitoring Gross Weight (reme modules only) for the HI 1746-WS Weigh Modu		
NOTE:	The HI WS100 will not read non-C2 load cell serial numbers.		
Reading Live Weight,	Step 1.	Click on the Live Weight Tab. The Live Weight page appears. (See Fig. 5-1) The Gross, Net and Tare weights are displayed.	

Thandy HI WS100 - D X Inte Une Weight Calibrate Parameters Setport Integrated Technician C2 Comm Setup Reading Weight Relay1 Genz: Weight Net Weight Relar 2 12-1 Tan Weight **ROCUME** ROC C Jueo G /min Ine to Zeo C /hou Motion . A/D Convetsion Error A/O Convertor Failure Excele Error

FIG. 5-1 LIVE WEIGHT PAGE

Step 2.

Taring the HI 1746-WS To Tare the HI 1746-WS click on the Tare button.

Zeroing HI 1746- WS	Step 3.	To Zero the HI 1746-WS click on the Zero button.
Relay 1 and Relay Status	Step 4.	The Relay 1 and Relay 2 status fields display only two values:
		• Low = O voltage output
		• High =5 volts output.
Setting the ROC Units	Step 5.	Click on the radio button next to the unit you want to use for the Rate of Change. (Default is Minute)
Errors	Step 6.	The lights next to Motion, Excite Error, A/ D Conversion Error and A/D Convertor Failure should all be green. A red light indicates an error in the weight readings.
Calibration Procedures	Step 1. Step 2.	Click on the Calibrate Tab. The Calibra- tion page appears. (See Fig. 5-2) HI WS100 gives you three choices for Calibration:
		C2 CalibrationHard CalibrationSoft Calibration
C2 Calibration	Step 3. Step 4.	Click in the radio button next to C2. The C2 Cal parameters appear. (See Fig. 5-2) Follow the instructions in the Text Area Field for C2 Calibration. For additional information consult your HI 1746-WS manual (Prt. #0596-0234-01) Chapter 5 - Calibration.

Hardy HI WS100				- 8
Intro Live Weight Calibrate	Parameters Setpoint Integr	ated Technician C2	Comm Setup	
Perform one of three calibr	ation methods Last Calibr	ation was Hard Cal		
Calbration Method	Cal Low Weight	0.000 bs	-	
C ≦ot	Span Weight	100.000 lbs		
	Capacity	450.000000		
	Sensitivity (n/V/V)	1.999600		
Remove all weight from a Enter the Cal Low Weight Cick on CalLow button Cick on Save button Enter your initials and dat	cale orplace Cal Low Weight o t value	n scale		
Callow	ldyh	Served		
Calibrated by:(2 initials)	VS on day 21 mont	h 2 year 2000		

FIG. 5-2 C2 CALIBRATION

Hard Calibration Procedures	Step 1.	Click on the radio button next to Hard Cal- ibration. The Hard Calibration parameters appear. (See Fig. 5-3)
	Step 2.	Follow the instructions in the Text Area Field for Hard Calibration. For additional information consult your HI 1746-WS manual (Prt. #0596-0234-01) Chapter 5 - Calibration.

Perform one of three calibrat	ion methods Last Call	bration was Hard Cal	
Calbration Method C C2 C Hard	Cal Low Weight	0.000 bs	
. Tou	Span Weight	100.000 lbs	
	Capacity	450.000000	
	Sensitivity (n/V/V)	1.995600	
Remove all weight from sc 2 Enter value of Cal Low Wo 3 Clock on CalLow button 4 Place Span Weight on sca 5 Enter the Span Weight val- 6 Clock on CalHigh button 7 Click on Save button 8 Enter your initials and date	ale orplace Cal Low Weight ight le ue	on scale	
Callow Cal	Jiph Bevic	Senad	
	E	2 2000	

FIG. 5-3 HARD CALIBRATION

Soft Calibration

- Step 1. Click on the radio button next to Soft Calibration. The Soft Calibration parameters appear. (See Fig. 5-4)
- Step 2. Follow the instructions in the Text Area Field for Soft Calibration. For additional information consult your HI 1746-WS manual (Prt. #0596-0234-01) Chapter 5 -Calibration.

0	Live Weight	Calbrate	Parameter	: Setpoint In	legrated	Technician	C2	Comm Setu	P	
	Perform one of	three calls	ation metho	de Last C	albration	was Hard C	al			
	Calibration Mel C C2 C Hard	thod		Cal Low Weigh	• F	0.000 bs	_			
	(Ligot			Span Weight	E	100.000 lbs				
				Capacity	45	0.000000				
				Sensitivity (n/V.	N) [1	999600	_			
	1. Place Cal Lo 2. Enter value o 3. Enter scale C 4. Enter scale S 5. Click on CalL 6. Click on Saw 7. Enter your ini	w Weight o If Cal Low V apacity val ensitivity vo ow button e button fails and da	n scale /eight #e #ue le							
	Callow		d <u>∃</u> gh	Beve		Servel				
(Calibrated by: (2)	initials)	MS of	day 21 n	onth 2	year 2	000			

FIG. 5-4 SOFT CALIBRATION

Setting Parameters

- Step 1. Click on the Parameter Tab. The Parameter page appears. (See Fig. 5-5)
- Step 2. Set the Tare weight Double click in the Tare Weight field and enter the Tare Weight Value. The Tare Value is an artificial zeroing of the weight hopper so that a new weight can be displayed. Also, the action of adjusting out the known weight of the container from the total indicated weight, so that the indicator reads net weight directly. You must click in the check box next to Tare Enabled to enable the Tare Function.
- Step 3. Set the Weight Unit of measure The Weight Unit of Measure can be set to either kilograms or pounds. Any weight value input to the module (e.g. CAL-LO, CAL-HI setpoints) are in the currently selected units. The unit of measure can be set at any time, not just at calibration. Setting the unit of measure before calibrating reminds the user what unit of measure is

being displayed. It is important to note that the weigh scale module does not need to be calibrated again after changing the unit of measure.

Step 4. Set the WAVERSAVER level - There are 5 selectable levels. 0 provides the least vibration immunity with the fastest response time. 4 provides the most vibration immunity with the slowest response time. The Default setting is 2. Click on the pull down menu next to WAVERSAVER and click on your selection.

b Live Weight	Calbrate Parameter	F Setpoint Integrated	Technician C2	Comm Setup	
Tate Weight	2.026 bs	Version 1.2			
Weight Units	C Klonen	C Zero Trac	k Enabled		
WaterCauer	1 million	F Tare Ena	bled		
m dreta dret	1.00 Herz	Zero Ena	bled		
NumAverages	1	크			
ROCTimeBase	1				
ZeroTolerance	22.046 bs	-			
AutoZeroTolerance	22.046 b)	-			
MotionTolerance	3.000 lbs	-			
Save					

FIG. 5-5 PARAMETERS SETTINGS

Step 5. Set the Number of Averages (NumAverages) - Click on the up or down arrow to reach the value you want or double click in the field and enter the value. The range is 1-255. The Number of Averages sets the number of weight readings which will be used to compute the displayed weight. The average is a sliding average so that a new average reading is available for display at every reading.

Step 6.	Set the ROCTimeBase - Click on the up
-	or down arrow to reach the value you want
	or double click in the field and enter the
	value. The Rate of Change Time Base is
	the time period you want for weight sam-
	pling to determine the Rate of Change,
	either loss in weight or gain in weight. The
	range is 1 - 1800 seconds
Step 7	Set the Zero Tolerance - Double click in
step /.	the Zero Tolerance field. The default value
	is 10 units of measure Enter the new Zero
	Tolerance value. The range is 1 to 32766
	Zero Tolerance sets the range of weights
	so that the Zero Command works as an
	offset of the calibrated Zaro. Zaro Tolar
	onset of the calibrated Zero. Zero Toler-
	ance is the number of graduations from
	zero that will be accepted as zero by the
	the sheal has next to "Zero Folerance click in
	the check box next to Zero Enabled so
	that a check mark is visible. The operator
G / 0	can reset this value at any time.
Step 8.	Set the Auto Zero Tolerance - The
	default value is 10 units of measure. The
	range is 1 to 32/66.
	• Double click in the Auto Zero Tol-
	erance field
	 Enter a positive value that does not
	exceed the maximum zero tolerance
	value or is not a negative value
	 Click in the check box next to "Zero"
	Track Enabled" to activate Auto
	Zero Tolerance tracking
	The Auto Zero Tolerance setting
	automatically sets the Zero Toler-
	ance so that the Zero Command
	works as an offset of the calibrated
	Zero
Step 9	Set the Motion Tolerance Value - Click
Step 7.	in the Motion Tolerance field and enter the
	motion value. The motion tolerance is the
	tolerance value used to determine if the
	scale is in motion. If the motion is outside

	Step 10.	the motion value entered, the light next to Motion Tolerance will turn to red. When the scale motion is within the tolerance the light turns green. Click on the Save button to save the new parameters.
Set Point Setup Procedures		
About Set Points	The set po be set in n the set poi gized dep HI 1746-V in HI WS	bint value is the target weight or level. It may net, gross or Rate of Change (ROC). When int is reached a relay is energized or de-ener- ending what you want the relays to do. The VS has two output relays which can be setup 100 Configuration Software.

Step 1. Click on the Setpoint Tab. The Setpoint page appears. (See Fig. 5-6)

etpoint 1	Selpoint 2
Value 10.000 bo	Value 10.000 bs
Preact 2.000 bs	Preact 0.000 lbs
Deschand 5.000 bs	Deadband 1.000 lbs
Setpoint Mode Tigger when weight is above setpoint Value Tigger when weight is below setpoint Value Force output high Trong or Excitation error Tigger on not Excitation error	Setpoint Node C Tagger when weight is above setpoint Value C Tagger when weight is below setpoint Value C Force output high C Force output high C Tagger on Excitation error C Tagger on Excitation error
Value Units	Value Units
C Net	C Net
@ Gross	Gross
C ROC	C ROC

FIG. 5-6 SETPOINT SCREEN

Three General Rules for Set Points

- 1. Set points activate at the set point plus the preact.
- 2. Set points deactivate at the set point plus the deadband.

- 3. The deadband should be numerically larger than the preact to prevent relay chatter.
- Step 2. Double click in the Value field.
- Step 3. Enter the desired set point value.
- Step 4. Double click in the Preact field.
- Step 5. Enter the desired Preact value. Preact is the number of units above or below the set point value of which the relay will trip. Use as an "in flight" compensation value.
- Step 6. Double click in the Deadband field.
- Step 7. Enter the desired Deadband value. Deadband is a value used to prevent relay chatter once the setpoint is reached. You can use positive or negative values. The negative value can be used as a low trip limit, the positive value can be used as a high trip limit.
- Step 8. Click in the radio button next to the Setpoint Mode you want.
- Step 9. Click in the radio button next to the Value units you want to read the weight. Gross, Net, or ROC.
- Step 10. Click on the Save button to save the settings.

Reading C2 Load Cell Serial Numbers

- Step 1. Click on the C2 Tab. The C2 page appears. (See Fig. 5-7)
- Step 2. Go to the Hardy Internet Site (http:// www.hardyinst.com) where you can look up the parameters of your load cell(s).

C2 Serial Number			
Load sense	#1 1	1	
Load sense	#2	1	
Load serus	#3	1	
Load sense	114	[
Load sense	#5	l	
Load sense	#6	1	
Load sense	#7	1	
Load serve	#B	1	

FIG. 5-7 C2 SERIAL NUMBER SCREEN

Remote Screen	Step 1.	Click on the Remote Tab. The Remote page appears. (See Fig. 5-8)			
NOTE:	The Remote Display will only appear if the HI 1746-WS module is installed in a remote chassis, with the jumper set to the remote mode of operation.				
	Step 2.	The Remote screen is a quick way to mon- itor gross weight of an HI 1746-WS mod- ule, installed in a remote chassis and operating in the remote mode. This screen gives the user a faster Gross Weight read- ing than the Live Weight display.			
	Step 3.	The indicator lights for Motion, and A/D Conversion and A/D Converter should all be green in normal operation. A motion red light means the scale exceeds the Motion Tolerance setting. A/D Conversion and A/D Converter red lights means a mal- function.			

💷 Hardy H	I WS100							_ # ×
Intro Li	ive Weight Calibrate	Parameters :	Setpoint	Integrated Techni	cian C2	Comm Setup	Remote	
r								
	Reading Weight							
			1.6.	_				
	Gross Weight	10.02	/ 105	_				
	 Motion 	•	A/D Car	rwassion Error				
		•	A/D Cor	wertor Failure				
-								
						Wedne	nday, Febru	ary 16, 2000

FIG. 5-8 REMOTE DISPLAY

CHAPTER 6 - TROUBLESHOOTING

A Brief Description of Chapter 6

Chapter 6 provides instructions on how to use Hardy Instruments INTEGRATED TECHNICIANTM to perform various tests for fault isolation troubleshooting of the load cells in your weighing system. INTEGRATED TECHNICIAN used in conjunction with the HI 2215IT Junction Box can tell you which load cell is not functioning properly, thereby eliminating the necessity of having to physically go to the load cell for testing. You can see from your PC desktop which cell is not working properly.

IT Troubleshooting

Step 1. Click on the Integrated Technician tab. the Integrated Technician page appears. (See Fig. 6-1)

Number of	Sensors (JBox on)	M [1 🚊	1			
Loadce	II Impedance Bate R St8 3 ohme	Read R 308.3 ohn	Test R Good	Sense V 5.107 volts	Current 16.565 mA	
RIZ	combined PASS	sensor 1	sensor 2	sensor 3	sensor 4	
DVM m₩ m₩/AV	combined 0.0 w// -0.0001 m///	sensor 1	sensor 2	sensor 3	sensor 4	
<u>System</u>	Test Internal S2.733 combined	Ref J Box F	sel	sensor 3	sensor 4	

FIG. 6-1 INTEGRATED TECHNICIAN TEST

- Step 2. In the "Number of Sensors (JBox only)" field you will see an up and down arrow. A few things need to be said about this field.
 - If you have all C2 load cells and an HI 215IT Junction Box, when you calibrate

the instrument, HI WS100 automatically loads the number of C2 load cells that are incorporated in your weight system. The number will automatically display in the Number of Sensors field. Having the HI 215IT Junction Box enables the configuration software to list the test results for each individual load cell in your weighing system.

- If you have non-C2 load cells and an Hi 215JT Junction Box, then you need to add the number of load cells in your system by clicking on the up or down arrows or double clicking in the field and typing the number, to enter the number of load cells in your weight system. Having the HI 215IT Junction Box enables the configuration software to list the test results for each individual load cell in your weighing system.
- If you do not have the HI 215IT Junction Box, the configuration software will give you a combined test result of all the load cells in your weighing system. (See Fig. 6-1)
- Step 3. Click on the Test button. After a second or two the results of the test will appear in the fields. The tests are:
 - 1. Loadcell Impedance
 - Base R is the impedance at the time of the last Calibration.
 - Read R is the impedance reported during the test.
 - Test R indicates whether the cell is good or bad.

Keep in mind that if you have the HI 215IT Junction Box the Test R result will appear for each load cell. Therefore you will know exactly which load cell failed. If you do not have an HI 215IT Junction it will

NOTE:

give a combined fail result but not for the specific load cell that failed. You will still have to determine which Load Cell failed.

- 2. Return to Zero Test (RTZ) This test returns a pass/fail result on whether there is a zero load.
 - If you have an HI 215IT Junction Box, individual load cells can be tested.
 - If you do not have an HI 215IT Junction box the result will be for the combined load cells in your weighing system.
- 3. Digital Volt Meter (DVM) This test returns the voltage outputs from the load cells.
 - If you have an HI 215IT Junction Box, the voltage output for each individual load cell is read.
 - If you do not have an HI 215IT Junction box the voltage output read will be for the combined load cells in your weighing system.
- 4. System Test Reads the weight for the load cells in your system.
 - If you have an HI 215IT Junction Box, the weight for each individual load cell can be read as well as the internal reference.
 - If you do not have an HI 215IT Junction box the weight read will be combined weight for all the load cells in your weighing system.